

SERVICE PARTS LIST PPS220

Parts No	Description
2	Left saucer and trivet
3	Left outer burner cap
4	Left inner burner cap
5	Right saucer and trivet
9	2# Burner
10	Left gas valve
13	1#gas tube
15	Right gas valve
16	1# Burner
20	Knob
21	Knob seat
25	Right outer burner cap
26	Right inner burner cap
33	Stove foot

